

Diagonal parking keys

 + 	Park the spindle in the upper left corner Press the  +  keys to park the spindle to the left and to the rear simultaneously.
 + 	Park the spindle in the upper right corner Press the  +  key to park the spindle to the right and to the rear simultaneously.
 + 	Park the spindle in the lower left corner Press the  +  key to park the spindle to the left and to the front simultaneously.
 + 	Park the spindle in the lower right corner Press the  +  key to park the spindle to the right and to the front simultaneously.

Return to [the keypad overview](#).
Continue to [the table of contents](#).

From:

<https://manualscyborg-engraverscom.webhosting.be/> - cyborg-engravers

Permanent link:

https://manualscyborg-engraverscom.webhosting.be/doku.php?id=en:x200:park_xy&rev=1745316859

Last update:

2025/04/22 12:14

