

## Park spindle in the rear



The PARK Y+ function  +  will move the spindle assembly to the very rear of the engraving table.

### Activating Park Y+.

Press the SHIFT  key and then the X-Y+-AXIS ARROW  to park the spindle in the rear left corner of the engraving table.

Keypad status bar displays:  
"Parking ..."

**Return to [the keypad overview](#).**  
**Continue to [the table of contents](#).**

From:  
<https://manualscyborg-engraverscom.webhosting.be/> - cyborg-engravers

Permanent link:  
<https://manualscyborg-engraverscom.webhosting.be/doku.php?id=en:x300:koppeling&rev=1664138515>

Last update: 2022/09/25 22:41

