

Parking keys

 + 	Park the spindle in the upper left corner Press the  +  keys to park the spindle to the left and to the rear simultaneously.
 + 	Park the spindle in the upper right corner Press the  +  key to park the spindle to the right and to the rear simultaneously.
 + 	Park the spindle in the lower left corner Press the  +  key to park the spindle to the left and to the front simultaneously.
 + 	Park the spindle in the lower right corner Press the  +  key to park the spindle to the right and to the front simultaneously.

Return to [the keypad overview](#).

Continue to [the table of contents](#).

From:

<https://manualscyborg-engraverscom.webhosting.be/> - cyborg-engravers

Permanent link:

<https://manualscyborg-engraverscom.webhosting.be/doku.php?id=en:x300:parking&rev=1664309029>

Last update: 2022/09/27 22:03

