

Option de menu "Autocadrage" (F5)

La méthode **Autocadrage** permet à l'utilisateur de créer une mise en page avec plusieurs lignes de texte rapidement. Elle fera en sorte que les textes seront distribués d'une manière équilibrée en fonction de la taille de la plaque disponible. L'opérateur peut adapter l'espacement des marges et ajuster le pourcentage de l'occupation du texte, en déterminant la hauteur de ligne idéale et l'espacement entre les lignes. Cette fonction est particulièrement utile pour des pendentifs ou plaques siganlétiques avec une zone spécifique où la gravure doit être positionnée.

Image écran "Autocadrage"

The screenshot shows the 'Autoplate' software window. It has a blue header bar with the title 'Autoplate' and a close button. The main area is divided into several sections:

- Dimensions plaque:** Contains input fields for 'Largeur:' (180.00 mm) and 'Hauteur:' (100.00 mm).
- Nombre de lignes:** A dropdown menu showing the value '3'.
- Lignes nouvelles ou existantes?:** A section with a description and two radio buttons: 'Créer cadrage' (selected) and 'Ajouter au cadrage existant'.
- Appliquer ces données?:** Two buttons labeled 'Oui' and 'Non'.
- Détails ligne:** A section with input fields for 'Texte pourcentage:' (44.00 %), 'Marges pourcent:' (10.00 %), 'Marge en haut:' (0.00 mm), 'Marge en bas:' (0.00 mm), 'Marge à gauche:' (6.10 mm), and 'Marge à droite:' (6.10 mm).
- Table:** A table with 4 columns: 'Ligne', 'Rapports', 'Ht ligne', and 'Bloquer'. It contains 3 rows of data.

Ligne	Rapports	Ht ligne	Bloquer
1	1.00	14.67	☐
2	1.00	14.67	☐
3	1.00	14.67	☐
- Preview:** A large black rectangular area on the right side of the window, representing the final layout of the plate with three white horizontal bars.

Le dialogue **Dimensions plaque** permet à l'utilisateur de configurer les dimensions de la plaque et le nombre de lignes de texte. La partie avec les **Détails Ligne** section Individual line heights can be tweaked through the line details table at the bottom by either adjusting the ratio value of the line or locking in a specific line height. Unless the tick box at the bottom is ticked, the autoplate will reformat any existing lines on the plate to suit the new layout defined. The preview pane on the right will update to reflect the changes made.

Line details

- **Text Occupies (%)**:

The percentage in height covered by sum of the hights of the text lines in comparison with the total plate height.

For example, if your plate is 60 mm high, the "**Text Occupies**" value is 50%, the sum of the line hights will always remain 30 mm (50% of 60 mm). 3 lines of equal height will be 10 mm each.

- **Margin Percent (%)**:

The percentage of the left and right margins' widths in comparison with the plate width.

A Margin percent of 10% on a sheet of 100 mm wide will result in a left and right margin of 10

mm each.

- **Top Margin**
- **Bottom Margin**
- **Left Margin**
- **Right Margin**

Line details table

- **Line:**
- **Ratios**
- **Line Ht**
- **Locked** (checkbox)

Access through...

- the **[F5]** function key on the keyboard
- the **Autoplate** shortcut  in the shortcut lists on the left
- the **Plate** menu and selecting **Autolayout**.

From:
<https://manualscyborg-engraverscom.webhosting.be/> - **cyborg-engravers**

Permanent link:
https://manualscyborg-engraverscom.webhosting.be/doku.php?id=fr:symmetry:option_autoplate&rev=1663164712

Last update: 2022/09/14 16:11

