

Redémarrer ou continuer le travail de gravure

Continuer un travail de gravure après une pause

Pour démarrer un travail de gravure, ce travail doit être chargé dans la mémoire de la télécommande virtuelle. Lorsque tel est le cas, son nom est visible dans le rectangle central de la télécommande virtuelle.

Pour démarrer le travail, cliquez sur l'icône Démarrer . Après avoir cliqué sur cette icône, le travail démarre et l'icône Pause s'affiche à la place de l'icône Démarrer.

Pour suspendre le travail n'importe où, cliquez sur l'icône Pause . Après avoir cliqué sur cette icône, le travail se met en pause et l'icône Redémarrage s'affiche à la place de l'icône Pause.

Pour reprendre le travail, cliquez sur l'icône Redémarrer . La tâche continue là où elle a été interrompue et l'icône Redémarrer est à nouveau remplacée par l'icône Pause.

Repeating a just engraved job

If you need to engrave the same job several times, you engrave it once, put a new plate on the table,

and you hit the Start   icon twice.

you can repeat this as many times as you like, the machine will repeat the last engraved job everytime.

Passez à [un aperçu de la télécommande virtuelle](#).
Passez à [la table des matières](#).

From:

<https://manualscyborg-engraverscom.webhosting.be/> - cyborg-engravers

Permanent link:

https://manualscyborg-engraverscom.webhosting.be/doku.php?id=fr:x300:restarting_job_console&rev=1720528213

Last update: 2024/07/09 14:30

