

De machine initialiseert niet

Controleer het volgende:

1. Is de voedingskabel goed verbonden tussen het muur stopcontact en het voedingssocket achteraan de X-300 ?
2. Controleer of het muur stopcontact de gewenste spanning levert? Controleer de spanning met een multimeter.
3. Zijn de twee glaszekeringen in het filterblok waar ook de voedingskabel insteekt nog OK? Die zekeringen zitten in een houdertje juist naast het voedingssocket. Controleer met een Ohm-meter.
4. When switching on the machine, do you hear the fan and do you hear the motors locking? If not, the power switch might be defective.
5. If the power switch is OK, the 48 VDC power supply might be defective. It feeds the fan and the step drives.
6. With the protective cover OPEN, and trying to home the spindle  + , do you see an image over the pendent indicating that you should close the cover ?
7. If you see this image and the machine does still not look for its home when pushing  + , you need to call your dealer.

Continue to [trouble shooting, spindle does not rotate](#).

Continue to [the table of contents](#).

From:

<https://manualscyborg-engraverscom.webhosting.be/> - cyborg-engravers

Permanent link:

https://manualscyborg-engraverscom.webhosting.be/doku.php?id=nl:x300:machine_not_initializing&rev=1670363786

Last update: **2022/12/06 22:56**

