

De hoofdschakelaar aan en uit zetten

de hoofdschakelaar aan zetten

Vooraleer deze schakelaar aan te zetten controleer je of de voedingskabel goed vastzit in het stopcontact achteraan de machine enerzijds en in het muur stopcontact anderzijds.



Om de machine aan te zetten plaats je de tuimelschakelaar achteraan de machine in de I stand. (zie afbeelding links.) Het is niet belangrijk in welke volgorde je de machine aanzet en het programma op de pc opstart.

de hoofdschakelaar uit zetten

Vooraleer deze schakelaar uit te zetten controleer je of de machine niet meer beweegt, of ze niet aan het graveren is.



To switch off the power you toggle the rocker switch at the rear of the machine to the 0 position. (see image on the right.) It is not important in which order you switch off the machine and the program.

Continue to [fixing the engraving material to the table.](#)

Continue to [the table of contents.](#)

From:
<https://manualscyborg-engraverscom.webhosting.be/> - cyborg-engravers

Permanent link:
https://manualscyborg-engraverscom.webhosting.be/doku.php?id=nl:x300:switching_on_off&rev=1669806899

Last update: 2022/11/30 12:14

