

The Zoom function

The **Zoom** function is only accessible through the three icons in the **icon bar** at the top of your Symmetry screen, or through the corresponding **shortcut** on the left of your main screen.

The Icon bar

■ Previous Zoom State



After having zoomed in one or several times, you can return to the previous zoom state by clicking on the **Previous Zoom State** icon.

■ Zoom In



When selecting the **Zoom In** icon, you can select a specific area in your job screen by clicking opposite corners of the area you want to view. Any combination of corners (top left and bottom right, top right and bottom left, etc.) will work.

■ Zoom Out



Clicking on the **Zoom Out** icon will have you return to the full view of your current engraving job.

The Shortcuts



There is a single zoom shortcut available, which will work differently, depending whether you selected a single text line or not.

■ Line selected

With a text line selected, clicking the zoom shortcut will have Symmetry zoom in onto the text line in question.

■ No line selected

Clicking the zoom shortcut will have Symmetry zoom out to the entire job.

From:

<https://manuals.cyborg-engravers.com/> - **cyborg-engravers**

Permanent link:

<https://manuals.cyborg-engravers.com/doku.php?id=de:symmetry:zoom>

Last update: **2023/06/16 09:42**

