

The Cyborg pendent only shows one tab in the preferences. How do I bring up the other two?

From:
<https://manualscyborg-engraverscom.webhosting.be/> - cyborg-engravers

Permanent link:
https://manualscyborg-engraverscom.webhosting.be/doku.php?id=en:faq-troubleshooting:pendent_settings_one_tab_only&rev=1745839710

Last update: 2025/04/28 13:28

