

How to open the electronics drawer


Important notes:

1. Before opening the electronics drawer, make sure to switch off the power to the machine.
2. Remove the power cord from the power socket.
3. Remove the ethernet cable from the ethernet socket.



On the above image the green arrows indicate the 2 screws which have to be removed.

Follow the 4 steps below to take off the timing belt from the spindle.



Gently pull the drawer to the rear.

When you encounter a resistance push the 2 sides down and pull further backwards.

Continue to [greasing the leadscrews](#).

Continue to [the table of contents](#).

From:
<https://manualscyborg-engraverscom.webhosting.be/> - cyborg-engravers

Permanent link:
https://manualscyborg-engraverscom.webhosting.be/doku.php?id=en:x200:machine_opening_the_drawer&rev=1745417698

Last update: 2025/04/23 16:14

