

Unpacking and checking the contents of the box

Unpacking

zie handleidingen Roland en GCC ?

- Place the box on the floor, near the table or workbench where you want to install the machine
- Open the cover
- Take out the accessories and place them on your tabletop or benchtop.
- Check the contents of your delivery using the checklist in the paragraph below.
- Clear your tabletop or benchtop and store all accessories in the vicinity.
- **Attention: this is a 2 person job!** Lift the machine out of the box and place it on your workbench or table.

After having unpacked, we advise you not to throw away the packing material. You might need it later when you need to move the machine to a new location or eventually, to ship the machine back to your vendor for service or repair.

Check the contents of the box




Image	Item description	Quantity	Checkbox
	Engraving machine Cyborg X-300	1	
	Cutter stand (cutters and knobs not included)	1	
	Cutter 3.175 mm x 125 mm, cutting width 0.2 mm	1	

Image	Item description	Quantity	Checkbox
	Cutter knob 3.175 mm	1	
	Vacuum hose 2 m	1	
{afbeelding}	Wrench for cutter knob (2 mm)	1	
	Power Cord	1	
	CAT6A ethernet cable	1	
	USB stick with software and registration code	1	
	Sticky mat 300 mm x 200 mm	1	
{afbeelding}	Cable for vacuum or auxiliary output	1	



From:

<https://manualscyborg-engraverscom.webhosting.be/> - **cyborg-engravers**

Permanent link:

https://manualscyborg-engraverscom.webhosting.be/doku.php?id=en:x300:box_contents&rev=1663069470

Last update: **2022/09/13 13:44**

