

Load a job from the computer



The “DNC” which you see on the key, refers to “Direct” or “Distributed Numerical Control”, a technique to transfer data from a computer to a machine controller.

This function key will allow you to access files directly from the host computer’s memory. DNC allows you to load jobs without the engraving program running.

- Press the DNC  function key.
An Explorer window will open in which you can choose the right folder. When in the right folder, double-click the job you want to engrave, or single-click on the jobname and confirm with the “Open” button in the lower right corner of your window.
- The message field on the virtual pendent will display the following message:
| jobname (name of the job)
| Press START.
- Press one of the following function keys to execute the proper command:
 - START  - Will execute the selected job file.
 - CANCEL  - Will cancel out the selected job file.
 - PAUSE  - Will allow you to change a tool, while holding the file in queue.
- When the file is finished running, the display will return to the main screen.

From:

<https://manualscyborg-engraverscom.webhosting.be/> - **cyborg-engravers**

Permanent link:

https://manualscyborg-engraverscom.webhosting.be/doku.php?id=en:x300:dnc_key&rev=1664094612

Last update: **2022/09/25 10:30**

