

Go home

The "Go Home"*hot key* functions as a return to 0,0 soft home and tool lift key.*Press the GO HOME hot key*
.Keypad status line display:
"Going Home ..."

From:
<https://manualscyborg-engraverscom.webhosting.be/> - **cyborg-engravers**

Permanent link:
https://manualscyborg-engraverscom.webhosting.be/doku.php?id=en:x300:go_home_key&rev=1664053095

Last update: **2022/09/24 22:58**

