

Go home



The "Go Home" hot key functions as a return to 0,0 soft home and tool lift key.
Press the GO HOME hot key. *Keypad status line display:*
"Going Home ..."

From:

<https://manualscyborg-engraverscom.webhosting.be/> - **cyborg-engravers**

Permanent link:

https://manualscyborg-engraverscom.webhosting.be/doku.php?id=en:x300:go_home_key&rev=1664053333

Last update: **2022/09/24 23:02**

