

Park spindle in the rear



The PARK Z  +  function will move the spindle assembly to the absolute Z 0 position or all the way up.

Activating Park Z.

Press the SHIFT  key and then the Z-AXIS JOG UP ARROW  to raise the spindle assembly to the absolute Z 0 position.

Keypad status bar displays:

“Parking ...”

Return to [the keypad overview](#).

Continue to [the table of contents](#).

From:

<https://manualscyborg-engraverscom.webhosting.be/> - cyborg-engravers

Permanent link:

<https://manualscyborg-engraverscom.webhosting.be/doku.php?id=en:x300:koppeling&rev=1664137667>

Last update: 2022/09/25 22:27

