

Shift

Pressing the SHIFT hot key before pressing any desired hot key will allow you to toggle between the Normal Hot Key and the Shifted Hot Key functions. When the SHIFT key has been pressed, the SHIFT ARROW will change colour to indicate you are in Shifted Mode.

From:

<https://manualscyborg-engraverscom.webhosting.be/> - **cyborg-engravers**

Permanent link:

https://manualscyborg-engraverscom.webhosting.be/doku.php?id=en:x300:shift_key&rev=1641475116

Last update: **2022/01/06 14:18**

