


Cancel temporary home / return to last home



labelling="Cancel the temporary home." data-bbox="67 194 374 211">

When using this key combination the X and Y coordinate fields in the virtual pendent will no longer show the 0.00 mm coordinate.

Instead you will see the coordinates count between the machine origin and the spindle position above the engraving table.

Returning to Machine Home. Press the SHIFT  and then the SET HOME  hot keys.

Then push  to make the spindle return to the machine home.

labelling="Return to last home after machine reboot." data-bbox="67 359 470 376">

When using this key combination the X and Y coordinate fields in the virtual pendent will no longer show the 0.00 mm coordinate.

Instead you will see the coordinates count between the machine origin and the spindle position above the engraving table.

Returning to Machine Home. Press the SHIFT  and then the SET HOME  hot keys.

Then push  to make the spindle return to the machine home.

Return to [the keypad overview](#).

Continue to [the table of contents](#).

From:
<https://manualscyborg-engraverscom.webhosting.be/> - cyborg-engravers

Permanent link:
https://manualscyborg-engraverscom.webhosting.be/doku.php?id=en:x300:shift_set_home_key&rev=1664103516

Last update: 2022/09/25 12:58

