

"Pointer Ruler Guides" menu option

The **Pointer Ruler Guides** menu option is a simple checkbox:

- Activating this will turn your mouse cursor into a crosshair, allowing the operator to move or place the cursor in a precise position with reference to other objects on the lay-out.
- Deactivating will have your cursor return to the standard arrow-shaped Windows cursor.

From:
<https://manualscyborg-engraverscom.webhosting.be/> - cyborg-engravers

Permanent link:
https://manualscyborg-engraverscom.webhosting.be/doku.php?id=es:symmetry:option_pointer_ruler_guides&rev=1650611095

Last update: 2022/04/22 09:04

