


Auxiliary outlet



Apart from a vacuum cleaner, the Cyborg X-300 is also able to control another auxiliary device. The X-300 controller can switch a aux. device on and off automatically at the beginning and at the end of an engraving job.

To do so there is a dedicated 24 VDC outlet at the rear of the machine. In fact there are 2 identical outlets.


The upper one is meant to control an auxiliary device.



If this icon is shown on the virtual pendent, the aux outlet will be powered.



If this icon is shown on the virtual penden, the aux outlet will not be powered.



Every X-300 comes with a short cable with plug to put in the “dust collector” outlet, or in the “aux” outlet.

The purpose is to switch on and off a 24 VDC relay which in turn can switch an auxiliary device on and off.

If you need to use both outlets, you will have to purchase a second cable with plug.

Clicking on the icon will alternate between the 2 possible choices.

Return to [the keypad overview](#).

Continue to [the table of contents](#).

From:

<https://manuals.cyborg-engravers.com/> - **cyborg-engravers**

Permanent link:

https://manuals.cyborg-engravers.com/doku.php?id=es:x300:aux_key

Last update: **2022/09/24 22:25**

