

Déballer et contrôler le contenu de la boîte

Déballer

- Mettez la boîte sur le sol, à côté de la table sur laquelle vous voulez installer la machine.
- Ouvrez la boîte.
- Retirez délicatement la machine et les accessoires et placez-les sur votre table.
- Vérifiez le contenu de votre livraison à l'aide de la liste de contrôle dans le paragraphe ci-dessous.
- Débarrassez votre table et rangez tous les accessoires à proximité.
- Attention : c'est un travail à 2 personnes! pour sortir la machine de la boîte et la placer sur l'établi ou la table.

After having unpacked, we advise you not to throw away the packing material. You might need it later when you need to move the machine to a new location or eventually, to ship the machine back to your vendor for service or repair.

Check the contents of the box




Image	Item description	Quantity	Checkbox
	Engraving machine Cyborg X-300	1	
	Cutter stand (cutters and knobs not included)	1	
	Cutter 3.175 mm x 125 mm, cutting width 0.2 mm	1	

Image	Item description	Quantity	Checkbox
	Cutter knob 3.175 mm	1	
	Vacuum hose 2 m	1	
	Wrench for cutter knob (2 mm)	1	
	Power Cord	1	
	CAT6A ethernet cable	1	
	USB stick with software and registration code for Pendent software and for Symmetry engraving software	1	
	Sticky mat 300 mm x 200 mm	1	

Image	Item description	Quantity	Checkbox
	Cable for vacuum or auxiliary output	1	

Continue to [the X-300 cable connections](#).
Continue to [the table of contents](#).

From:
<https://manualscyborg-engraverscom.webhosting.be/> - **cyborg-engravers**

Permanent link:
https://manualscyborg-engraverscom.webhosting.be/doku.php?id=fr:x300:box_contents&rev=1700581485

Last update: **2023/11/21 16:44**

