

Menukeuze "Autolayout" (F5)

De **Autolayout**-methode laat de gebruiker toe om snel een layout te creëren met meerdere tekstregels, die evenwichtig gespreid worden over het beschikbare plaatoppervlak. Gebruikers kunnen de linker- en rechtermarges wijzigen, maar evenzeer de tekstdekking aanpassen, en de ideale regelhoogte en regelspatiëring bepalen. Deze functie kan bijzonder nuttig zijn wanneer er een specifieke ruimte beschikbaar is waarbinnen uw ontwerp dient te passen.

Autolayout schermvoorbeeld

The screenshot shows the 'Autoplate' dialog box with the following sections:

- Plaat Afmetingen**:
 - Breedte: 120.00 mm
 - Hoogte: 100.00 mm
- Aantal regels**: 3
- Nieuwe of bestaande regels?**:
 - Met deze gegevens een nieuwe layout creëren, of ze bijvoegen bij de bestaande regels?
 - ☐ Creëer Layout
 - ☒ Voeg deze regels toe aan bestaan
- Deze gegevens toepassen?**:
 -
- Regel Details**:
 - Tekst dekking: 44.00 %
 - Marges Procent: 10.00 %
 - Bovenmarge: 0.00 mm
 - Ondermarge: 0.00 mm
 - Linkermarge: 6.10 mm
 - Rechtermarge: 6.10 mm
- Table**:

Regel	Ratios	Regel Ht	Geblokk...
1	1.00	14.67	☐
2	1.00	14.67	☐
3	1.00	14.67	☐
- Preview**: A black rectangular area on the right showing three white horizontal bars representing the text lines.

The dialog allows the user to configure the size of the plate, and the number of lines. The **Line Details** section Individual line heights can be tweaked through the line details table at the bottom by either adjusting the ratio value of the line or locking in a specific line height. Unless the tick box at the bottom is ticked, the autoplate will reformat any existing lines on the plate to suit the new layout defined. The preview pane on the right will update to reflect the changes made.

Line details

- **Text Occupies (%)**:

The percentage in height covered by sum of the heights of the text lines in comparison with the total plate height.

For example, if your plate is 60 mm high, the "**Text Occupies**" value is 50%, the sum of the line heights will always remain 30 mm (50% of 60 mm). 3 lines of equal height will be 10 mm each.

- **Margin Percent (%)**:

The percentage of the left and right margins' widths in comparison with the plate width.

A Margin percent of 10% on a sheet of 100 mm wide will result in a left and right margin of 10

mm each.

- **Top Margin**
- **Bottom Margin**
- **Left Margin**
- **Right Margin**

Line details table

- **Line:**
- **Ratios**
- **Line Ht**
- **Locked** (checkbox)

Access through...

- the **[F5]** function key on the keyboard
- the **Autoplate** shortcut  in the shortcut lists on the left
- the **Plate** menu and selecting **Autolayout**.

From:
<https://manualscyborg-engraverscom.webhosting.be/> - **cyborg-engravers**

Permanent link:
https://manualscyborg-engraverscom.webhosting.be/doku.php?id=nl:symmetry:option_autoplate&rev=1651756071

Last update: 2022/05/05 15:07

