

Menukeuze "Cursor in kruisvorm"

De menukeuze **Cursor in kruisvorm** is een eenvoudig vinkvakje:

- **Activeren** this will turn your mouse cursor into a crosshair, allowing the operator to move or place the cursor in a precise position with reference to other objects on the lay-out.
- **Deactiveren** will have your cursor return to the standard arrow-shaped Windows cursor.

From:

<https://manualscyborg-engraverscom.webhosting.be/> - cyborg-engravers

Permanent link:

https://manualscyborg-engraverscom.webhosting.be/doku.php?id=nl:symmetry:option_pointer_ruler_guides&rev=1655386759

Last update: 2022/06/16 15:39

