

De graveerjob herstarten of verderzetten

De graveerjob verderzetten

Om de graveerjob te starten moet die job eerst in het geheugen van de virtuele pendent geladen zijn. Als dat het geval is, is de naam zichtbaar in de centrale statusbalk in het virtuele toetsenbord.



Om de job te starten, klik op het  icoon. Na op dit icoon geklikt te hebben start de job en wordt het "pauze" icoon getoond in plaats van het "Start" icoon.



Om eerder waar de job te pauzeren, klik op het Pauze  icoon. Na het klikken van dit icoon pauzeert de job en het "ga verder" icoon wordt afgebeeld in plaats van het "Pause" icoon.



Om de job verder te zetten, klik op het "verdergaan"  icoon. De job wordt verdergezet waar hij gepauzeerd werd en het "verdergaan" icoon wordt vervangen door het "pauze" icoon.

Herhalen van een juist gegraveerde job

If you need to engrave the same job several times, you engrave it once, put a new plate on the table,



and you hit the Start  icon twice.

you can repeat this as many times as you like, the machine will repeat the last engraved job everytime.

Continue to [an overview of the virtual keypad](#).

Continue to [the table of contents](#).

From:
<https://manualscyborg-engraverscom.webhosting.be/> - **cyborg-engravers**

Permanent link:
https://manualscyborg-engraverscom.webhosting.be/doku.php?id=nl:x300:restarting_job_console&rev=1670163913

Last update: **2022/12/04 15:25**

